Quick Start

PANTECH BURST™

Get to Know Your Phone

Note: For more information about your Pantech Burst, visit **att.com/Device Support.**

Phone Setup

① Remove the battery cover.

② Insert the microSIM card and memory card (optional) into their respective slots. Ensure that the gold contacts of each card are facing down.

③ Align the gold contacts on the battery with the contacts located at the top of the battery compartment.

④ Close the battery cover.



Touchscreen

Navigate Your Phone

- Use your fingertip to lightly touch the screen.
- Use quick flicks of your finger on the touch-screen to scroll up/down and left/right.
- To return to the previous screen, press the **Back** ↩ key.
- Press **Home** ⌂ at any time to return to the main home screen.
- Press **Menu** ≡ to view options for the current screen.

Notification Bar

- The **Notification Panel** includes timely information about your phone, including new message, email, and voicemail notifications as well as missed calls and calendar reminders.
- Touch the **Notification Bar** and slide it down with your finger to open **Notification Panel** and see full details. Press the **Back** ↩ key to close the panel.



Find More Information

On the Web

- Interactive Web tutorials are available at **att.com/Tutorials**. Select Manufacturer: **Pantech** and Model Name: **Burst** from the drop down menus.
- Detailed support information including device specifications, troubleshooting, and user forums are available at **att.com/DeviceSupport**.
- For more about your wireless account, service plan, or network, visit **att.com/Wireless**.

On the Phone

- Call AT&T Customer Care at 1-800-331-0500; or
- Dial 611 from your wireless phone.

Find Accessories

AT&T has accessories for productivity, convenience, and fashion. You can also shop for accessories at **att.com/WirelessAccessories**.

Data and messaging charges may apply. Pantech® and Burst are both trademarks of Pantech Co., LTD, and/or its related entities. Android is a trademark of Google, Inc. ©2012 AT&T Intellectual Property. All rights reserved. AT&T, the AT&T logo, and all other AT&T marks contained herein are trademarks of AT&T Intellectual Property and/or AT&T affiliated companies. All other marks contained herein are the property of their respective owners.

Printed in Korea. 5U000604C0A REV.00

Customize Home Screens

① Touch and hold a blank space on one of the home screens. You will be presented with four options:

- **Shortcuts:** Access the items you use most with one touch.
- **Widgets:** View application information such as weather, social networking updates, etc., without having to open the full app.
- **Folders:** Add folders to organize contacts and shortcuts.
- **Wallpapers:** Change your home screen wallpaper.

Touch the option you desire and follow instructions.

② To move a widget, shortcut, or folder, touch and hold it and drag it to a new location.

③ To delete it, touch and hold it and drag it to the trash bin.



Calls and Voicemail

Make a Call

① From the home screen, tap **Phone**.

② Select an option to place a call:

- **Phone:** Manually enter telephone number.
- **Call Log:** Return or retry a call.
- **Contacts:** Call someone in your address book.

Check Voicemail

① From the home screen, tap **Phone**.

② Press and hold **1** on the virtual keypad.

③ If voicemail is not set up, follow the voice prompts to set the permanent password.

Ringtones

- To change the ringtone, from the home screen, tap **Menu key** > **Settings** > **Sound** > **Phone ringtone**, then tap the available ringtones and tap **OK**.
- To change the ringtone volume, press up or down on the **Volume** key when not in a call.

Network Indicators

Your 4G LTE wireless device will display one of the following network indicators to let you know which of AT&T's wireless networks you are connected to.

4G LTE Connected to AT&T's 4G LTE network.

4G Connected to AT&T's HSPA+ network.

E Connected to AT&T's EDGE/2G network.



Limited 4G LTE availability in select markets. 4G speeds delivered by LTE, or HSPA+ with enhanced backhaul, where available. Deployment ongoing. Compatible data plan required. LTE is a trademark of ETSI. Learn more at **att.com/network**.

A network indicator does not necessarily mean that you will experience any particular upload or download data speeds. Actual speeds depend upon a variety of factors, including the device, network utilization, file characteristics, terrain, etc. Learn more at **wireless.att.com/learn/articlesresources/wireless-terms.jsp**, Your AT&T Wireless Customer Agreement, Section 3.2 Where and How Does AT&T Service Work?

Camera

Take a Picture

① From the home screen, tap **Camera**.

② Touch **Shutter** to take the picture. To adjust settings, tap the screen to activate the setting options menu.

– Photos will automatically be saved in Menu > Gallery.

Send a Picture

① After the picture has been taken, tap **Share**.

② Select your option to send the picture and follow the on-screen prompts.

③ To post immediately to social networks, select or .



Note: To capture video, slide the mode switch (in the top right corner) to Camcorder.

Connectivity

Connect a Bluetooth® Headset

① From the home screen, tap **Menu**.

② Tap **Settings** > **Wireless & networks** > **Bluetooth settings**.

③ Tap **Bluetooth** to activate.

④ Tap **Scan for devices**.

⑤ Tap an available device, then tap **Pair** to connect.

Connect to Wi-Fi®

① From the home screen, tap **Menu**.

② Tap **Settings** > **Wireless & networks** > **Wi-Fi settings**.

③ Tap **Wi-Fi** to activate the signal.

④ Tap a network, enter the password if the network is secured, then tap **Connect**.



Note: Refer to documentation included with your Bluetooth device for information on pairing mode and password.

Text Messaging

Send a Text Message

① Tap **Messaging** from the home screen or applications menu.

② Tap **New Message**.

③ Type in the telephone number or tap to access the address book. Then tap the contact name you wish to select, and **Done**.

④ Tap **Type to compose**, and use the keyboard to enter your message. Tap **Send**.

Insert a Picture or Video

① While composing a message, press **Menu**.

② Tap **Attach** > **Picture** or **Video**.

③ Tap an album and then the picture or video in that album to attach it.

④ Tap **Send**.





Please don't text and drive.

Pay-per-use charges apply unless you have a messaging plan.

Email

Set Up Email

① From the home screen, tap **Email**.

② Enter the email address and password of the account you would like to set up and tap **Next**.

③ Enter the account and name as it will appear on outgoing messages, then tap **Done**.

Send Email

① From the home screen, tap **Email**.

② Tap **Compose Mail**.

③ Enter the email address or tap to access the address book. Then tap the contact name you wish to select and tap **Done**.

④ Then tap the **Subject field** to enter a subject and **Compose Mail** to enter email text.

⑤ When complete, tap **Send**.



Note: For Exchange ActiveSync®, contact your IT administrator to help set up your corporate Microsoft Exchange account. If you set up a Gmail account, it will sync with your other Google services like calendar and albums.

AT&T Services

Amazon Kindle™: Read Kindle books, magazines, and newspapers right from your mobile phone.

AT&T U-verse® Live TV: Watch live, on-demand & downloadable TV content including ESPN Mobile TV, Fox News, and more.

AT&T Code Scanner: Scan barcodes you find in magazines, in stores, and online and see video clips, get coupons, or learn more about your favorite products and services!

AT&T Navigator℠: Get voice-guided, turn-by-turn driving directions and traffic updates right on your phone!

YP®: Find restaurants, bars, businesses, and more, whether around the corner or across the nation.

Qik Lite: Video chat, record great moments as they happen, and share your videos with your friends.

Movies: Download and watch movies right on your phone.

Note: For more AT&T apps, visit the AT&T tab in Android Market.

AT&T U-verse Live TV requires mobile broadband service and is not available in all areas. Data usage and subscription charges may apply.

Apps

Access Android™ Market

① From the home screen, tap **Market**.

② Use your existing Google™ account or create one following the steps on the screen.

Navigate Android Market

- From the marketplace, you will have multiple options to select and search for apps and games.
  – Tap **Apps** to access apps by category.
  – Tap **Games** to access games by category.
  – Tap **AT&T** to access games and apps that can be directly billed to your AT&T account.
- Tap to search the marketplace for a specific game or app.
- Once installed, you will see a notification in the Notification Bar. Open the app from this notification or by tapping and locating the app.



Note: A Google Checkout payment method is required to purchase apps.

Social Networking

Access Social Networking Apps

① From the home screen, tap .

② Scroll to the Facebook or Twitter app and tap the application to open. If not logged in already, set up your account or log in to your existing account.

③ Once logged in, you can access or share updates, view and upload photos, send and receive messages, and more.

Use Social Networking Widgets

- Widgets allow you to see information such as tweets or status updates right on your home screen without opening the full application. From these widgets you can:
  – Tweet or update your status.
  – View news feed, tweets, or mentions.
  – Open the full app.




You are not logged in.
Log in by launching the Facebook application on your Android phone.
You are not signed in.
Tap to start using Twitter.

Note: This phone is preloaded with Facebook® and Twitter® apps. Other apps are available for download in Android Market.

Internet

Access the Internet

① From the home screen, tap **Web**.

② Scroll up and down the screen to navigate and tap links to open them. Double-tap on the screen to zoom in; double-tap again to zoom out.

③ To visit another Web site, tap **Search**, enter the Web site address, and tap .



Note: Tap **Menu** to view options such as add a bookmark, open a new browser window, and more.

Data charges may apply for Internet access.